

◎ 订货举例

系列代码	插管外径	—	螺纹大小	牙型代码
EMC	04: 4mm		M8: M8	P: PT
EML	06: 6mm		01: 1/8"	G: G
EMB	08: 8mm		02: 1/4"	
...	10: 10mm		03: 3/8"	
	12: 12mm		04: 1/2"	

订货举例： EMC系列意大利式铜镀镍金属接头，4mm插管外径，接管口径为PT1/8"，其ERP编码为：EMC04-01

◎ 型号

	型号 EMC06-M8 EMC06-01 EMC06-02 EMC06-03 EMC06-04 EMC08-01 EMC08-02 EMC08-03 EMC08-04	EMC10-01 EMC10-02 EMC10-03 EMC10-04 EMC12-01 EMC12-02 EMC12-03 EMC12-04		型号 EML04-M8 EML04-01 EML04-02 EML06-M8 EML06-01 EML06-02 EML06-03 EML06-04 EML08-01 EML08-02	EML08-03 EML08-04 EML10-01 EML10-02 EML10-03 EML10-04 EML12-01 EML12-02 EML12-03 EML12-04		型号 EMB04-M8 EMB04-01 EMB04-02 EMB06-M8 EMB06-01 EMB06-02 EMB06-03 EMB06-04 EMB08-01 EMB08-02	EMB08-03 EMB08-04 EMB10-01 EMB10-02 EMB10-03 EMB10-04 EMB12-01 EMB12-02 EMB12-03 EMB12-04
EMC			EML			EMB		
	型号 EMW06-M8 EMW06-01 EMW06-02 EMW06-03 EMW06-04 EMW08-01 EMW08-02 EMW08-03 EMW08-04	EMW10-01 EMW10-02 EMW10-03 EMW10-04 EMW12-01 EMW12-02 EMW12-03 EMW12-04		型号 EMSC06-M8 EMSC06-01 EMSC06-02 EMSC06-03 EMSC06-04 EMSC08-01 EMSC08-02 EMSC08-03 EMSC08-04	EMSC10-01 EMSC10-02 EMSC10-03 EMSC10-04 EMSC12-01 EMSC12-02 EMSC12-03 EMSC12-04		型号 EMH04-M8 EMH04-01 EMH06-M8 EMH06-01 EMH08-01 EMH08-02 EMH10-02 EMH10-03 EMH12-03 EMH12-04	
EMW			EMSC			EMH		
	型号 EMZT04-M8 EMZT04-01 EMZT04-02 EMZT06-M8 EMZT06-01 EMZT06-02 EMZT06-03 EMZT06-04 EMZT08-01 EMZT08-02	EMZT08-03 EMZT08-04 EMZT10-01 EMZT10-02 EMZT10-03 EMZT10-04 EMZT12-01 EMZT12-02 EMZT12-03 EMZT12-04		型号 EMP04-M8 EMP04-01 EMP04-02 EMP06-M8 EMP06-01 EMP06-02 EMP06-03 EMP06-04 EMP08-01 EMP08-02	EMP08-03 EMP08-04 EMP10-01 EMP10-02 EMP10-03 EMP10-04 EMP12-01 EMP12-02 EMP12-03 EMP12-04		型号 EMF04-M8 EMF04-01 EMF04-02 EMF06-M8 EMF06-01 EMF06-02 EMF06-03 EMF06-04 EMF08-01 EMF08-02	EMF08-03 EMF08-04 EMF10-01 EMF10-02 EMF10-03 EMF10-04 EMF12-01 EMF12-02 EMF12-03 EMF12-04
EMZT			EMP			EMF		
	型号 EMU04 EMU06 EMU08 EMU10 EMU12			型号 EMV04 EMV06 EMV08 EMV10 EMV12			型号 EME04 EME06 EME08 EME10 EME12	
EMU			EMV			EME		
	型号 EMZA04 EMZA06 EMZA08 EMZA10 EMZA12			型号 EMM04 EMM06 EMM08 EMM10 EMM12			型号 EMCF04-M8 EMCF04-01 EMCF04-02 EMCF06-M8 EMCF06-01 EMCF06-02 EMCF06-03 EMCF06-04 EMCF08-01 EMCF08-02	EMCF08-03 EMCF08-04 EMCF10-01 EMCF10-02 EMCF10-03 EMCF10-04 EMCF12-01 EMCF12-02 EMCF12-03 EMCF12-04
EMZA			EMM			EMCF		

1

气动控制元件

2

流体控制元件

3

电气控制元件

4

气动执行元件

5

气源处理元件

6

真空元件

7

洁净元件

8

高真空元件

9

气动辅助元件